



Installation Guide

***24-25 Toyota Tacoma / 22-25 Tundra/
Sequoia / 25 4Runner DoubleTap
Dual Color LED Projector
Fog Lights***



This installation guide provides a detailed, step-by-step process for installing your new Alpharex fog lights for 23+ Toyota Sequoia.

DO NOT USE DIELECTRIC GREASE / REMOVE ANY DEBRIS OR ANY PRE-EXISTING GREASE OR WEATHER SEALANT

Contents

Step 1: Remove the OEM Fog light	P1
Step 2: Install the Alpharex fog lights	P5

Tools needed:

- 10mm / Ratchet
- Philips head screwdriver
- Trim removal tool
- Wire pulling device

Step 1 - Remove the OEM Fog light

Removal of OEM Fog light difficulty: 2 / 5

1.1 - The first step in removing the fog lights is to take out the four 10mm bolts securing the bottom of the bumper on each side. (A total of four bolts per side.)



1.2 - Now that the bolts are removed, you can proceed to remove the shroud covering the fog lights.

1.3 - There are a total of twelve clips at front and two screws behind securing the shroud. Begin by unclipping the clips one by one to prevent any from breaking, then proceed to remove the screws.



Step 1 - Remove the OEM Fog light

1.4 - Once all the clips are released, you should be able to carefully pull the shroud back, as shown.



1.5 - Now, remove the screws at the back, and the shroud should come off completely.



Step 1 - Remove the OEM Fog light

1.6 - With the shroud removed, you can now access and remove the OEM fog lights. They are secured by two screws and connected to the vehicle with a single plug.

1.7 - First, disconnect the plug from the back of the fog light.



1.8 - Now, remove the two screws securing the fog light in place. These screws can be accessed from the front of the light, with one located on the right side and the other on the left.

1.9 - The inner screw on both sides will be easy to access with it being exposed however the outer screws will require you to pull back on the bumper from the pictured place to have enough room to unscrew the screw.

Step 1 - Remove the OEM Fog light



1.10 - Just like that, the fog light can now be fully removed.



Step 2 - Install the Alpharex fog lights

2.1 - It's time to install your new Alpharex fog lights

2.2 - Grab your light and simply reverse the removal steps, as these are plug-and-play for easy installation.



2.3 - Once the new fog light is installed, you will notice an extra yellow wire with a single connector. This wire connects to the additional harness that sits between the headlight and the vehicle's turn signal connection.



Step 2 - Install the Alpharex fog lights

2.4 - First, route the wire from the fog light to the back of the headlight. We used a small claw-like tool to help pull it up for easier access.



2.5 - It should connect to the back of the headlight as so.



Step 2 - Install the Alpharex fog lights

2.6 - Then the single yellow wire will connect directly to the male yellow wire on that harness.



2.7 - Once you make that final connection, the installation is complete! Now, simply reinstall all the body panels, and you're good to go!

