


ROCK SLIDERS

24+ TOYOTA TACOMA

SRTT1-04



TOOLS REQUIRED

- 16mm wrench or socket
- Safety Glasses

SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- 2 Hours

Time to install this should only take about 2 Hours.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information


1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (20) M10x35mm Bolts
- (20) M10 Lock Nuts
- (20) M10 Flat Washers



STEP 1 | (If equipped) Remove factory steps or rock rails.

Ensure the (10) threaded frame holes are clear of any dirt or factory plugs.





STEP 2 | Bench press the slider up to the body of the truck.

Loosely mount the sliders in place using the provided M10 hardware.

Use (1) split washer and (1) flat washer per M10 bolt.

Note: An extra set of hands is helpful to hold the slider in place while starting the hardware by hand.



INSTALLATION MANUAL

STEP 3 | Adjust the height of the sliders to your preference starting at the rear of the truck.

Secure the M10 bolts and slider in place using a 16mm socket or wrench.



STEP 4 | Double check that all hardware is secure.



INSTALLATION MANUAL

STEP 5 |

Congratulations, installation of the DV8 Tacoma Rock Sliders is now complete.

