

21+/FORD RAPTOR

PHANTOM REAR BUMPER

PREPARATION

We recommend reading through the installation instructions in whole before performing the work.

- · Disconnect the negative battery terminal. Park the vehicle on level ground and set the emergency brake.
- When button head bolts are being used, install the supplied washer on the nut side. Then, hold the bolt stationary and only turn the nut to tighten. Do not turn the bolt to tighten hardware assembly, unless otherwise noted.
- Anti-seize is recommended for all fasteners.



This installation requires 2 people for best results



- 8- Nylon Lock Nuts (1/4-20")
- 8- Button Head Bolts (1/4-20 X 1")
- 8- Flat Washer (1/4")
- 4- Hex Head Bolt (3/8-16 x 1 1/2")
- 4- Nylon Lock Nuts (3/8-16")
- 8- Flat Washers (3/8")
- 2- Snap-in Nuts
- 2- Sheet metal Screw (1/4"")



- 2 hours for OEM Removal/Bumper Install -1 Additional Hour to Wire Cube Lights

Labor Rates are based on a vehicle with no pre-existing damage. Wiring labor is based on a standard wiring procedure with light switches installed in an easily accessible location. Custom light triggering or switch mounting location will result in a greater labor charge.



(Sockets) 7/16, 9/16, 10mm (Box end wrenches) 7/16, 9/16, 10mm (Allen wrenches) 5/32

(Torx) T40

Fastener remover or flathead screwdriver

Grinder

Zip ties

Ratchet




PHANTOM REAR BUMPER

21+/FORD RAPTOR

REMOVAL



Unplug the main wire harness located on the passenger side by pulling the gray tab back as shown below. Remove the ground using a (10mm socket) located on the passenger side on the frame rail.









PRO-BOLT ON REAR BUMPER

22+/ FORD F-150

STEP 2


Unplug/remove the trailer plug.

REMOVAL



☐ STEP 3

Remove the license plate light by twisting counter clock wise and remove the housing.



Page 3 | Addictive Desert Designs



PHANTOM REAR BUMPER

21+/FORD RAPTOR


REMOVAL

☐ STEP 4

Remove the parking sensors and bezels from the stock bumper, You can now remove the wire harness and set aside for install. **Remember the location and orientation of the sensor bezels after removal for this will be important later on in the install**



SPREAD THESE TWO TABS
TO RELEASE THE PARKING
SENSOR.



SQUEEZE THESE TWO TABS TO RELEASE THE PARKING SENSOR MOUNTING RINGS.



PHANTOM REAR BUMPER

21+/FORD RAPTOR

REMOVAL



Pull the top plastic cover off the bumper. There are no tools required for this step, it simply pulls off by hand.





PHANTOM REAR BUMPER

21+/FORD RAPTOR

REMOVAL



Using a (T40 torx), remove the mounting bolts that hold the bumper side covers to the vehicle.






PHANTOM REAR BUMPER

21+/FORD RAPTOR

REMOVAL

STEP 7

Remove the license plate bracket by using a (grinder) to grinding through the five visible welds that connect that bracket to the hitch. **Once the bracket has been removed, paint over the raw metal to prevent rust**








PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Install the license plate light housing. Be sure that the clips are fully clipped in by using a (flathead) to pry into place. **DO NOT pry to hard due to breakage**





PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Install the trailer plug and pry out the tabs to securely seat plug using a (flathead screwdriver).





PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Install the parking sensor mounts using the 1/4" button head bolts, washers, and nylon lock nuts using a (5/32 allen) and (7/16 wrench). (Repeat on other side) **Install the sensor bezels in the orientation you remove them from the stock bumper**










PHANTOM REAR BUMPER

21+/FORD RAPTOR

INSTALLATION



☐ STEP 11

If your sensor bezels do not click into place, you may have to trim the mounting tabs to accommodate for the thickness of the material on your new bumper.

BEFORE



AFTER





PHANTOM REAR BUMPER


INSTALLATION

21+/FORD RAPTOR



Unplug the outer parking sensors by pushing the white tab down. Insert the plug through the provided cutout next to the sensor mounts. Plug the parking sensor back in and ensure the sensor is facing the direction provide in the bottom right picture.








PHANTOM REAR BUMPER


INSTALLATION

21+/FORD RAPTOR



Install the light mount brackets using the provided 1/4" button head bolts, washers, and nylon lock nuts using (5/32 allen wrench) and a (7/16 wrench). (Repeat on other side)







PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Using a (T40 torx) install your new ADD bumper using the 0EM hardware from the bottom mount you removed on step 6.





PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Install the provided 3/8" hex head bolts, washers, and nylon lock nuts using a (9/16 socket) and a (9/16 wrench) for the top mounting holes.. **Ensure the bolt is facing in the directions shown in the pictures below**








PHANTOM REAR BUMPER

INSTALLATION

21+/FORD RAPTOR



Plug in the wire harness, and reinstall the ground using a (10mm). **Ensure the clip is fully pushed down when plugged in as shown below**









PHANTOM REAR BUMPER

FINAL

21+/FORD RAPTOR



Stand back and enjoy your new ADD Phantom[™] rear bumper.

Check and re-tighten, if needed, all mounting bolts after 100 miles and periodically thereafter.